

Construct drop and overflow from ductile iron pipe of same diameter specified for sewer main. Provide mechanical joints for all ductile iron pipe and fittings.

- 1 Place Class I bedding material, CLSM, flowable mortar, or concrete from top of elbow to bottom of sewer main.
- 2 Encase elbow in concrete. 12 inches minimum on all sides.




FIGURE 6010.307 SHEET 10