



(NON-BARNROOF FORESLOPE)


Grading Surface:


Refer to berm slope location table in project plans for locations of A, B, W and possible other points.

- 1 Variable slope.
- 2 Bridge Berm slope may vary and is determined by the A and B points. Slope is normally 2.5:1 or flatter
- 3 Refer to contract documents for limits of the slope protection.









- 2 Bridge Berm slope may vary and is determined by the A and B points.
- 3 Refer to contract documents for limits of the slopeprotection.
- 4 Refer to BR series for longitudinal subgrade slope.
- (5) Temporary grading slope.
- g = Pavement cross slope.

