


- For joint details, see PV-101.
- ① Build curb to end of Reinforced Bridge Approach Section. See Curb Location Details (Section B-B on BR-101).
 - ② See BR-101.
 - ③ Longitudinal Joint (PV-101):
Single Pour - Saw cut joint per Detail B.
Two Pours - Use 'KS-1' joint.
 - ④ 'CD' Joints required up to 300 feet each way from end of Reinforced Bridge Approach Section.
 - ⑤ Excavation limits of Modified Subbase 2 feet outside of pavement edge, see BR-101.
 - ⑥ Slope subdrain to drain.
 - ⑦ Place an "X" in the plastic concrete near the 'EF' joint at the outside edge of pavement.
 - ⑧ Place 'RD' joint where PCC shoulder. Place 'B' joint otherwise.


PLAN VIEW



SECTION THRU CENTERLINE

Possible Contract Item:
Bridge Approach, Two Lane

Possible Tabulation:
112-6



DETAIL 'B'
Doweled PCC Pavement

	REVISION	
	1	10-17-17
STANDARD ROAD PLAN		BR-102
REVISIONS: Changed DR-304 to DR-306.		SHEET 1 of 1
 APPROVED BY DESIGN METHODS ENGINEER		
BRIDGE APPROACH SECTION (TWO-LANE, ABUTTING PCC PAVEMENT)		